

LD2546



DECAPPING DIE

Works on cases up to .560" in diameter and up to 3.125" long

INSTRUCTIONS: Screw decapping die into press until it touches the shell holder and tighten the lock ring finger tight. The decapper is retained by a collet. Should it be overstressed by an obstruction, it simply slides up without damage. To reset, loosen the decapper clamp and position the decapper flush with the clamp end and tighten. *Considerable torque force may be necessary.* A 1/2" and 3/4" wrench are required. Replacement decapper, order #90783



WARNING: Steel parts may be alloyed with trace amounts of lead and other elements, which are known to the state of California to cause reproductive harm and cancer. For more information, go to www.P65Warnings.ca.gov. To prevent exposure, do not alter the product by welding, grinding, etc.

©2020 PRINTED IN USA

LEE

LEE PRECISION, INC.
4275 COUNTY ROAD U · HARTFORD WI 53027
www.leeprecision.com

DECAPPING DIE





DELUXE
APP / **AUTOMATIC
PROCESSING
PRESS**

**Decap/size brass,
swage primer pockets
or size bullets as fast as
you can pull the handle.**

90933
Deluxe APP
90951 APP

LEE
LEE PRECISION, INC.

